

ADJUSTABLE ALUMINIUM
LAPTOP/CONTROLLER **STAND**

User Manual



creator[®] series

ADJUSTABLE ALUMINIUM LAPTOP/CONTROLLER STAND



UDG's Aluminium Laptop/Controller Stand is ideal for DJ's who need to elevate their laptop or iPad and controller above any flat and stable surface. UDG's Aluminium Laptop/Controller Stand is design to accommodate a smallest iPad to a larger laptop computer or other comparable size / weight component. It's the only laptop stand for DJ's that balances, solid, secure construction, portable, foldable, height and angle adjustable, 360-degrees rotatable, low-weight design and excellent afford ability. UDG's Aluminium Laptop/Controller Stand is easy and fast to assemble.

Item Code : U6010BL

Item Description : UDG Laptop/Controller Stand Aluminium Black



creator[®] series

Table of Contents

1 General Information	4
1.1 Specifications	4
1.2 Help with this Manual	5
1.3 About this Manual	5
1.4 Information and Safety Notes	5
1.5 UDG Contact Information	5
2 Operation of UDG laptop/Controller Stand	6
2.1 Operation Procedures	6
2.1.1 Unpacking and Inspection	6
2.1.2 Parts Included	6
2.1.3 Position	7
2.1.3.1 Open	7
2.1.3.2 Upright Position	7
2.1.3.3 360 Degrees Rotatable of Main Tray	8
2.1.3.4 Closed	8
2.1.4 Features	9
2.1.4.1 Knob	9
2.1.4.2 Lever Clamp	9
2.1.4.3 Sub Tray	10
2.1.5 Proper Usage	11
2.1.5.1 Setting Up	11
2.1.5.2 Tearing Down and Fold	13
2.1.6 Storing the Equipment	13
2.1.7 Warnings	13
3 Limited Lifetime Warranty	14
4 About UDG	15

1. General Information


- Solid and easy to assemble laptop/controller stand for DJs/producers
- High quality aircraft grade anodized aluminium
- Height adjustable
- Angle adjustable
- 360° rotatable
- Removable sub tray
- Fit's 13" - 18" laptop, iPad or controller
- Airflow constructed tray prevents equipment from overheating
- Protective neoprene sleeve included

1.1 Specifications

Product Dimension


Fully extended

(H/W/D) 42 x 34 x 28 cm / 16.5 x 13.4 x 11 inches



Folded

Only 4.5 cm / 1.8 inch thick folded



Weight

1.6 kg / 3.5 lbs

1.2 Help with this Manual

For UDG, customer service is the highest priority. If for any reason you have any questions that are not covered in this manual, please feel free to contact us.
See section 1.5 for the UDG Contact Information.

1.3 About this Manual

This manual has been made to ensure that our customer can easily understand and use the UDG Laptop/Controller Stand. All the information in this manual is correct and complete. We always welcome our customers suggestions for improvements to our product and associated publications.

1.4 Information and Safety Notes

Throughout this manual you will find text under headings **NOTE:** and **CAUTION:**

Under **NOTE:** headings, you will be given additional information pertinent to the subject discussed in that paragraph or step.

Example :

NOTE: *Ignoring either of these cautions will void the warranty and could result in damage to the UDG Laptop/Controller Stand or gear.*

Under **CAUTION:** headings, you will be alerted to potentially hazardous conditions which, if ignored or mishandled, could result in damage to the equipment or your UDG Laptop/Controller Stand.

Example :

CAUTION: *DO NOT attempt to rotate the Clamp Lever exceed from the maximum clamping point. It will loosen the clamping pressure.*

1.5 UDG Contact Information

Email : info@udggear.com

Website : www.udggear.com

Customer Service : info@udggear.com

2. Operation of UDG Laptop/Controller Stand

This section guides you in operating UDG Laptop/Controller Stand. If you Should require additional assistance, please feel free to contact UDG customer service.

2.1 Operation Procedures

2.1.1 Unpacking and Inspections

First when you receive your order, check the shipping container condition. If the shipping container appears damages in any way, contact the shipping company immediately. Keep all damaged packing materials to assist in liability for damage.

Carefully inspect your UDG Laptop/Controller Stand while you unpack. If any damages is noted, or if parts appear to be missing, email UDG customer service at info@udggear.com.

2.1.2 Parts Included

Now that you have unpacked your UDG laptop/Controller Stand, take a moment to familiarize yourself with your new UDG Laptop/Controller Stand and all of the components.



No.	Item Description	Qty
1	Main Tray	1
2	Sub Tray	1
3	Lever Clamp	2
4	Leg Assembly	2
5	Knob Assembly	2
6	Height Fastener	1

2.1.3 Positions

CAUTION: NEVER attempt to adjust any component position without first unlocking the Lever Clamp.

CAUTION: NEVER unlock the Lever Clamp or attempt to adjust position while your gear is on the stand.

NOTE: Ignoring either of these cautions will void the warranty and could result in damage to UDG Laptop/Controller stand or gear.

2.1.3.1 Open

This UDG Laptop/Controller Stand offers an unlimited combination of angle settings giving the user absolute freedom to achieve comfort and reliability.

NOTE: KNOW YOUR PRODUCT. It is incredibly important to take a few minutes to find the desired position. We recommend trying all position, adjust, until you find the most comfortable position for you to put your gear on it.

After you have found the desired position, we recommend practicing the adjustment procedure mentioned later in this manual.

2.1.3.2 Upright Position

The upright position is the standard position that we recommend for most laptops and other equipment.



You can always adjust the height of your UDG Laptop/Controller Stand, for your most comfortable position.

Rotate the Height Fastener to loosen or tighten so you can adjust the height level of your UDG Laptop/Controller Stand. Rotate clockwise to tighten. Rotate counter clockwise to loosen.

CAUTION: The maximum height adjustment of UDG Laptop/Controller Stand when fully extended is 47 cm. NEVER increase the height level above it.

NOTE: Ignoring the maximum height level can cause instability of the UDG Laptop/Controller Stand and could result falling object or gear.

2.1.3.3 360 Degrees Rotatable of Main Tray

This UDG Laptop/Controller Stand offers an unlimited combination of angle settings giving the user absolute freedom to achieve comfort and reliability.

CAUTION: Be sure to loosen the Height Fastener before you wish to rotate the main tray to desired angle.



2.1.3.4 Closed

This is the position that suitable to storage and travel.



Sub Tray

Folded Laptop/Controller Stand

CAUTION: When it folded, give sufficient force to tighten the Lever Clamp to have a fix folded shape.

CAUTION: Please always protect your UDG Laptop/Controller Stand into UDG Neoprene Sleeve to have proper protection for travel.

NOTE: Ignoring either of these cautions may cause a damage to UDG Laptop/Controller Stand when travel. That condition will void the warranty.

2.1.4 Features

CAUTION: NEVER attempt to adjust any component position without first unlocking the Lever Clamp.

CAUTION: NEVER unlock the Lever Clamp or attempt to adjust position while your gear is on the stand.

NOTE: Ignoring either of these cautions will void the warranty and could result in damage to UDG Laptop/Controller Stand or gear.

2.1.4.1 Knob

The aluminium knurled Knob is useful to adjusting Lever clamping pressure for your UDG Laptop/Controller Stand. To have the best clamping pressure you have to adjust the knob by :

- a) Rotate clockwise to increase Lever clamping pressure.
- b) Rotate counter clockwise to decrease Lever clamping pressure.

CAUTION: DO NOT OVER TIGHTEN the Knob when setting your UDG Laptop/Controller Stand.

NOTE: Ignoring this caution will accelerate to wear the Lever Clamp.




2.1.4.2 Lever Clamp

The UDG Laptop/Controller Stand is using the aluminium Lever Clamp. It is comfortable for you to clamp the setting position of the leg and tray of the UDG Laptop/Controller Stand.

The Lever Clamp was adapted the ex-center method.

The picture below will explain you which part of Lever Clamp will give you the best point of clamping.




CAUTION: DO NOT attempt to rotate the Clamp Lever exceed from the maximum clamping point. It will loosen the clamping pressure.

NOTE: Ignoring this caution can cause instability of the UDG Laptop/Controller Stand and could result falling object or gear.

There are two positions of the Clamp Lever that must be followed :

1. On the bottom Leg. The Lever Clamp position should be parallel with the Leg.
See picture below :



CAUTION: This is recommended bottom Lever Clamp position.

2. On the top Main Tray. The Lever Clamp should be positioned downward.
See picture below :



CAUTION: This is recommended top Lever Clamp position.

CAUTION: NEVER attempt to loose or unlock the Lever Clamp while your gear is on the stand. Please always set your UDG Laptop/Controller Stand before you start to put the laptop or gear on the stand.

NOTE: Ignoring either of these cautions will void the warranty and could result in damage to UDG Laptop/Controller Stand or gear.

2.1.4.3 Sub Tray

The aluminium Sub Tray of UDG laptop/Controller Stand is special. It was light and removeable. Once you have it set, it will precisely positioned and affordable to hold a specific weight of the DJ's equipment.



CAUTION: DO NOT put equipment which exceed dimension than the Sub Tray.

NOTE: Ignoring this caution can cause falling object or gear.

2.1.5 Proper Usage

This section will give you clear explanation of recommended usage of UDG Laptop Controller Stand. This will give you an easy overview about how to set UDG Laptop Controller Stand quickly and safely.

2.1.5.1 Setting Up

Step 1 : From folded shape, release both Lever Clamp by rotating out and away from the clamping point.



Step 2 : Make sure both Leg and Main Tray rotate freely.

NOTE: If they do not rotate freely, immediately reduce clamping pressure by rotating Knob counter clockwise.

Step 3 : Lift and set your UDG Laptop/Controller Stand to desired position.




Step 4 : Set initial tension by rotating Knob clockwise.
Rotate the Lever Clamp to clamping position.
Rotate the Height Fastener to clamping position.

NOTE : Do not over tighten. Finger-tight should be more than sufficient

Step 5 : Put the Sub Tray into sub tray slot.

Gently feel if the sub tray sit on the right position on the sub tray slot.



Step 6 : Now your UDG Laptop/Controller Stand is standing up.

Check the clamping strength on the Main Tray and Leg by gently applying weight on it.



NOTE: If desired load capability is not met after checking, unlock the Lever Clamp and add more pressure by rotating Knob clockwise. Adjust the Knob in small increments.

Step 7 : Now your UDG Laptop/Controller Stand is ready to use.

Check it by putting the gear above the main Tray and Sub Tray.

Please be careful if there is any sagging.

NOTE: If you experienced sagging, follow step four to seven.



2.1.5.2 Tearing Down and Fold

Step 1 : Remove gear from UDG Laptop/Controller Stand.

Step 2 : Remove Sub Tray.

Step 3 : Loosen the Height fastener.
Move Main Tray side closer to the Leg.
Fasten again the Height fastener.

Step 4 : Loosen both Lever Clamp.

Step 5 : Fold the UDG Laptop/Controller Stand.
Rotate the Lever Clamp to clamping position.



2.1.6 Storing the Equipment

The best way to storing your UDG Laptop/Controller Stand is in folded shape. It will be less using of the space.

Always put your folded UDG Laptop/Controller Stand in the neoprene sleeves which is come together when you purchase. That is a proper protection to prevent from dust or dirt.

2.1.7 Warnings

2.1.6.1 Weight Overload

DO NOT exceed the Weight Load Limitations.
Maximum Weight Load Limitation is 00 Kg / 00 Lbs

2.1.6.2 Sagging

Sagging can occur when the load exceed the proper tension setting. if you experience sagging, follow the step four to seven in the Proper Usage section.

3. Limited Lifetime Warranty



Our guarantee is very straight-forward, and reflects our belief in the quality of our products. We sincerely believe that our products are the best in the World. We put our products through rigorous tests to ensure that the products you trust, are built to the highest standards. You will probably never encounter a problem with your UDG products. In the unlikely event that you, in the first two years from the date of purchase, discover a problem caused by defects in either workmanship or materials, we will be happy to see that it is fixed (or replaced, if we decide that would be best). We will even offer you a Limited Lifetime Warranty against manufacturer's defects.

Please be aware that we do not cover normal wear and tear, damage caused by airlines or other common carriers, any damaged contents of your UDG Laptop/Controller Stand products. We also do not cover any damage when our products have been in hands of a third party, before they were delivered by you.

It is important to note that our guarantee is not an unconditional guarantee. UDG products are made from the highest quality materials and produced under the highest manufacturing standards. Therefore, our guarantee does not cover product damage that may result from abuse or mishandling of the product or overloading. If an airline or other common carriers damages your product, you should file a damage claim with the carrier before you leave the airport. We also do not cover incidental or consequential damages, such as loss or damage to the contents of the bag, cd wallet or trolley. Locks are intended only to prevent accidental opening and cannot necessarily prevent theft of case of its contents. For repairs that are deemed by us as non warranty, the repair fee will be determined at the UDG repair facility. All warranty claims accompanied by an explanation with detail pictures and an original receipt of purchase, can be emailed to info@udggear.com. Damage due to wear and tear will be invoiced at a reasonable charge. We do not speculate at the store level or on the phone as to whether a fee will be assessed for the repair. Turn-around time on repairs is approximately 2-4 weeks from the time the product is received at our repair facility and we have your approval to complete the repair.

For complete warranty details go to : www.udggear.com

4. About UDG

UDG's Equipment is designed for the world's most frequent travelers: professional touring DJs, musicians, and music producers. Our products represents the culminations of over 20 years of experience creating the best products for the music industry and was designed to create the ultimate equipment for the mobile professional.

UDG stands for superb quality, innovation, comfort, style, and durability. Today the UDG product lineup has grown to a vast range of bags, cases and equipment to suit every need. UDG users all over the world rely on our products to protect their investments in equipments, vinyl records, CD's and DVD's. We stand behind our products, and we are proud when you choose a UDG product.

UDG specializes in ultimate no-compromise gear protection solutions for no-compromise artists.

Thank you for buying this product



Michael Schmeitz | Founder

UDG is a trademark of UDG USA Inc. registered in the US and other countries. Creator® is trademark of UDG. Other brands and products are trademarks of their respective holder/s. UDG reserves the right to modify its products at any time and without notice in order to better their quality and functionality. Therefore, all the information given in this brochure is to be considered indicative and subject to possible modifications. ©UDG USA Inc. All rights reserved.

The logo features the letters 'UDG' in a large, bold, sans-serif font. A registered trademark symbol (®) is positioned at the top right of the 'G'. Below 'UDG', the website address 'UDGGEAR.COM' is written in a smaller, all-caps, sans-serif font.

UDG[®]
UDGGEAR.COM

© UDG USA Inc. All Rights Reserved
U.S. & Foreign patents pending