

# electro-harmonix

## HEADPHONE AMP

Congratulations on your purchase of the Electro-Harmonix **HEADPHONE AMP!** Now you can rock out anywhere without disturbing your neighbors. Simply use a 9V battery and any pair of headphones you like, as long as they have an 1/8" plug attached to them.

### —CONTROLS —

**VOLUME** — Sets the output level.

**INPUT JACK** — Connect the output of your instrument or effects pedal to this 1/4" jack. The input impedance presented at the INPUT jack is 100 k $\Omega$ .

**OUTPUT JACK** — Insert the 1/8" stereo plug from your headphones into this jack.

### -OPERATION AND WARNINGS-

Power, from the internal 9-volt battery is activated by plugging into the output. The headphone cable should be removed when the unit is not in use to avoid running down the battery. A pop may occur in the headphones when inserting or removing the plug from the headphone jack.

To change the 9-volt battery, you must remove the 4 screws on the bottom of the **HEADPHONE AMP**. Once the screws are removed, you can take off the bottom plate and change the battery. Please do not touch the circuit board while the bottom plate is off or you may damage a component.

**- WARRANTY INFORMATION -**

Please register online at <http://www.ehx.com/product-registration> or complete and return the enclosed warranty card within 10 days of purchase. Electro-Harmonix will repair or replace, at its discretion, a product that fails to operate due to defects in materials or workmanship for a period of one year from date of purchase. This applies only to original purchasers who have bought their product from an authorized Electro-Harmonix retailer. Repaired or replaced units will then be warranted for the unexpired portion of the original warranty term.

If you should need to return your unit for service within the warranty period, please contact the appropriate office listed below. Customers outside the regions listed below, please contact EHX Customer Service for information on warranty repairs at [info@ehx.com](mailto:info@ehx.com) or +1-718-937-8300. USA and Canadian customers: please obtain a **Return Authorization Number** (RA#) from EHX Customer Service before returning your product. Include with your returned unit: a written description of the problem as well as your name, address, telephone number, e-mail address, and RA#; and a copy of your receipt clearly showing the purchase date.

**United States & Canada**

EHX CUSTOMER SERVICE  
ELECTRO-HARMONIX  
c/o NEW SENSOR CORP.  
47-50 33RD STREET  
LONG ISLAND CITY, NY 11101  
Tel: 718-937-8300  
Email: [info@ehx.com](mailto:info@ehx.com)

**Europe**

JOHN WILLIAMS  
ELECTRO-HARMONIX UK  
13 CWMDONKIN TERRACE  
SWANSEA SA2 0RQ  
UNITED KINGDOM  
Tel: +44 179 247 3258  
Email: [electroharmonixuk@virginmedia.com](mailto:electroharmonixuk@virginmedia.com)

This warranty gives a purchaser specific legal rights. A purchaser may have even greater rights depending upon the laws of the jurisdiction within which the product was purchased.

To hear demos on all EHX pedals visit us on the web at [www.ehx.com](http://www.ehx.com)  
Email us at [info@ehx.com](mailto:info@ehx.com)