


AVert



Contents

- Description** **3**
- Installation** **4**
- Specifications** **4**
- Diagram** **5**
- Functional Overview** **6**
 - 1. In 6
 - 2. Amp 6
 - 3. Out 6

Description

AVert is a dual attenuverter. Each channel offers the ability to attenuate and invert any input signal. The signal present at channel 1 is normalised to channel 2, allowing for two unique output signals from a single input. Get Inverted.

- Dual attenuverter
- Attenuates and/or inverts any input signal
- Normalising behavior offers two unique outputs for a single input
- Center detented pots provide tactile feedback for 0V


Installation

To install, locate 2 HP of space in your Eurorack case and confirm the positive 12 volts and negative 12 volts sides of the power distribution lines. Plug the connector into the power distribution board of your case, keeping in mind that the red band corresponds to negative 12 volts. In most systems, the negative 12 volt supply line is at the bottom. The power cable should be connected to the module with the red band facing the front of the module.

Specifications

- Size: 2 HP
- Depth 42mm
- Current Consumption:
 - +12V: 9mA
 - -12V: 5mA

Diagram



Functional Overview

Both channels are identical.

1. In

Input to the attenuverter.

The signal present at the first input will normal to the second channel if no connection is made to the second input.

2. Amp

Knob that controls the amount of attenuation and inversion applied to the signal at the input.

- If the knob is fully left, the output will be an inverted version of the input signal.
- If the knob is center, the output will be fully attenuated, and no signal will output.
- If the knob is fully right, the output will be identical to the signal present at the input.

3. Out

Output of attenuated and/or inverted signal.